


KELLY SPINNER - PNEUMATIC


Parts Illustration - 1/3



BVM CORPORATION
 430 S. NAVAJO STREET, DENVER CO 80223
 PHONE: 303-975-1402; FAX: 303-975-0981
 www.bvmcorp.com; sales@bvmcorp.com


KELLY SPINNER - PNEUMATIC

Parts Illustration - 2/3



KELLY SPINNER - PNEUMATIC

Parts Illustration - 3/3



BVM CORPORATION
430 S. NAVAJO STREET, DENVER CO 80223
PHONE: 303-975-1402; FAX: 303-975-0981
www.bvmcorp.com; sales@bvmcorp.com

KELLY SPINNER - PNEUMATIC

Parts List

ITEM NO.	PART NO.	QTY	DESCRIPTION
1	200602-C	1	SUB SHAFT
2	200600-B	2	SPINNER HOUSING
3	200604-E	2	BEARING AND SEAL RETAINERS
4	200604-2A	2	GREASE SEALS (BEARING & SEAL RETAINER); Timken 415656
5	200604-2B	2	GREASE SEALS (BEARING HOUSE TOP & BOTTOM); Timken 21086-3664
6	200603-C	2	SHIM SETS (1 BLUE & 1 YELLOW)
7	200604-T	1	TOP BEARING HOUSING
8	200603-B	2	HOUSING BEARINGS (1 CUP, 1 CONE per ASSEMBLY)
9	200604-F	2	SLINGER RING
10	200607-C	1	RING GEAR (SOLID)
11	200601-B	1	LOWER PLATE COVER
12	200604-B	1	BOTTOM BEARING HOUSING
13	200611-SMR	1	AIR STARTER ASSEMBLY - RIGHT TURN
14	200610-SML	1	AIR STARTER ASSEMBLY - LEFT TURN
15	1408C-12-5	16	HEX HEAD BOLT 1/2-13X1 1/2 (8 per RETAINER)
16	20080-00-0	16	1/2 LOCKWASHER
17	1412C-14-5	22	HEX HEAD BOLT 3/4-10X1 3/4 (8/6 per BEARING HOUSING & 6 FOR COVER)
18	20120-00-0	22	3/4 LOCKWASHER
19	1410C-14-5	12	HEX HEAD BOLT 5/8-11X1 3/4 (6 per GEAR & 3 PER AIR STARTER)
20	20100-00-0	12	5/8 LOCKWASHER
21	1410C-12-5	4	HEX HEAD BOLT 5/8-11X1 1/2 (2 per PAD EYE)
22	200605-P	2	PAD EYE
23	200690	2	MUFFLER
24	200672	2	1" - 1 1/4" PIPE BUSHING
25	200678	2	1" STREET ELBOW
26	200675	3	1" SHORT NIPPLE
27	200685	2	RELAY VALVE
28	10438	2	HOSE TO RELAY VALVE
29	200673	2	1" NPT - 1" BARBED FITTING
30	200688	1	1" ID HOSE
31	200680	1	1" PIPE TEE
32	200677	4	90 DEG ELBOW
33	200689	2	HOSE CLAMP
34	200693	1	1" NPT SQUARE HEAD PLUG
35	200605	2	1" DIA TURNBUCKLE, 18" TAKE-UP LENGTH